



Revised: April 2006

<p>Printed February 08</p>	<h1>Textrol (Clear)</h1> <h2>Penetrating Oil Finish</h2> <h3>Technical Data Sheet</h3>	
<p>Description Textrol is a high solids clear penetrating oil finish for exterior wood. Developed to penetrate deep in to the wood, it provides protection against moisture and sun damage at the same time enhancing the natural beauty of the wood, Textrol provides a mildew resistant finish which, because it is non film building, will not crack, peel or flake. When Textrol is first applied the wood will darken to a rich matt colour. It will then gradually lighten depending on the intensity of sun exposure</p> <p>Where to use Textrol Textrol may be used on soft or hardwoods; pressure treated timber, Cedar and Redwood, which has been allowed to weather. It is ideal for garden decks, fences, cladding, shake and shingle roofs, log homes and garden furniture</p> <p><u>TECHNICAL DATA</u></p> <p>Finish: Matt Freeze Thaw: Passes 3-5 cycles Shelf Life: At least 5 years when stored properly VOC: Does not exceed 550gms/litre Flash Point: 63°C Temperature Application: 5°C - 35°C</p> <p>Coverage Initial: - Smooth Wood: 5m²/ltr per 2 coats Rough sawn wood: 2.5m²/ltr per 2 coats Maintenance: - Smooth Wood: 10m²/ltr per 2 coats Rough sawn wood: 5m²/ltr per 2 coats</p> <p>Drying Time Textrol maybe walked on once absorbed in to the wood Fully dry after 24 – 48 hours, depending on temperature and humidity. Furniture and plants can be replaced after this time</p> <p>Application Method Brush, Roller, Stain Brush, Garden Sprayer, Low-pressure airless spray (.011 - .015 tip @ 700psi)</p> <p>Limitations For exterior use only Do not use on new wood Do not use on hardboard, plywood, or over previously stained, varnished or painted wood Do not use on screened in or enclosed areas Limited air circulation will slow or prevent the finish from curing</p> <p>Sizes 1ltr, 2.5ltr, 5ltr and 20ltr</p> <p>Colours Clear</p> <p>Tinting 5 to 10 grams of oil/spirit based tint per litre of Textrol 60mls of oil/spirit based transparent stain per litre of Textrol Use wood tone colours only Always test the tint first with two wet-on-wet coats on a small piece of wood to check for colour and uniformity before coating the entire surface</p>		

Revised: April 2006

<p>Printed February 08</p>	<h1>Textrol (Clear)</h1> <h2>Penetrating Oil Finish</h2> <h3>Technical Data Sheet</h3>	
<p>Clean Up Clean all tools and equipment with white spirit whilst still wet. If allowed to dry remove with paint stripper Any rags soaked in Textrol should be dipped in water before disposing with household waste Transfer leftover Textrol to a smaller, closed metal or glass container to prevent gelling Store and maintain equipment as directed by manufacturer</p> <p>Directions for use:</p> <p>SURFACE PREPARATION New Wood (Wood exposed to weathering for less than 12 months) 1. Treat new wood with Seasonite and allow to weather for 12 months 2. After 12 months follow Directions as for Weathered Wood</p> <p>Note The mill glaze and natural oils in new smooth Cedar prevent strong adhesion of any coating and the proper penetration of any oil. For new smooth Cedar apply Seasonite New Wood Protection as soon as the deck or cladding has been installed. Leave for 12 months then treat as for Weathered Wood</p> <p>Weathered Wood (Wood exposed to weathering for longer than 12 months) 1. Remove loose debris with soft brush or broom 2. Treat any Mildew with a solution of 1 part bleach to 3 parts water. Leave to stand for 15 minutes. Rinse with copious amounts of fresh water using the highest-pressure source available or a power washer. Proceed to point 3 3. Apply Net-trol Wood Cleaner & Colour Restorer following instructions on the container 4. Rinse off Net-trol with copious amounts of fresh water using the highest pressure source available or a power washer 5. Allow wood to dry thoroughly (2-3 warm dry days) before applying finish</p> <p>Wood Previously Coated other than with Textrol or Penetrating Oil Finish Textrol can only be applied to bare wood All previous coatings must be completely removed Apply Stripper/Cleaner (Prepdeck) and follow instructions on the container Once previous coatings are removed treat as for “New Wood”</p> <p>Note Clean vertical surfaces from bottom to top to avoid streaking Stripper/Cleaner may darken some woods such as Cedar, Redwood, Douglas Fir and Hardwoods. To restore colour use Net-trol Wood Cleaner & Colour Restorer diluted 1:4 with fresh water and apply to surface. Wait 10 minutes; then rinse with copious amounts of fresh water. Leave to dry 2-3 warm dry days before applying finish. Do not allow the surface to dry prior to using Net-trol</p> <p>APPLICATION 1. Shake or stir can well before using 2. Apply 1st coat of Textrol and allow to penetrate into the wood (15-30 minutes) Do not allow Textrol to become Touch Dry or Dry between coats 3. Apply 2nd coat of Textrol and leave to penetrate for 10-15 minutes 4. Wipe up any excess finish that has not penetrated after this time, to avoid shiny spots 5. Allow to dry</p> <p>Note Ensure end grain is liberally coated After spray application, back brush or back roll to improve penetration and uniformity of coverage</p>		

Revised: April 2006

Printed
February 08

Textrol (Clear) Penetrating Oil Finish

Technical Data Sheet



MAINTENANCE

Horizontal Surfaces

Textrol should be reapplied to horizontal surfaces every other year or as required depending on exposure to the sun and weather

Clean timber as directed under SURFACE PREPARATION for Weathered Wood.

Allow wood to dry (2-3 warm dry days) before applying finish

Apply a single coat of Textrol

Leave to penetrate 10-15 minutes.

Wipe up any excess finish that has not penetrated after this time to avoid shiny spots

Vertical Surfaces

Textrol should be reapplied to vertical surfaces every 3-5 years or as required depending on exposure to the sun and weather

Clean timber as directed under SURFACE PREPARATION for Weathered Wood

Allow wood to dry (2-3 warm dry days) before applying finish

Apply a single coat of Textrol

Leave to penetrate for 10-15 minutes

Wipe up any excess finish that has not penetrated after this time to avoid shiny spots

Good Application Practice

Cover everything you do not wish to treat including shrubs and plants

Do not apply in direct sunlight

Do not apply if cold wet weather is expected within 48 hours

Do not apply to hot wood as the finish may not penetrate properly

Health and Safety

Material Safety Data Sheets for this and all other Owatrol/Flood products are freely available from the place of purchase or the address below. Store in secure dry conditions inaccessible to children and animals. Containers should be kept closed during storage. Do not empty into drains, watercourses or access routes to septic tanks

Availability

Textrol is available through quality paint stores and timber merchants

For further information please contact the address below