



APPLICATION INSTRUCTIONS – KEIM DOLOMITSPACHTEL

KEIM Dolomitspachtel is a ready to use multipurpose, mineral based filler for interior use.

SURFACE PREPARATION

- All loose, flaking and unstable material must be identified and then thoroughly removed using stiff brushes and broad bladed scrapers to get back to a sound edge; these edges should then be feathered in.
- Ensure that any paint materials left remaining and the underlying substrate is sound and adhering well.
- Any gloss or shiny surfaces should be thoroughly flatted down using sand or emery paper to create a good key.
- Wash all surfaces with clean cold water to remove dust and dirt.
- For concrete substrates, a maximum residual moisture content of 3% must not be exceeded.

MATERIAL APPLICATION

1. KEIM Dolomitspachtel is supplied ready to use.
2. Apply thinly with a float, and do not exceed a maximum layer thickness of 4mm.
3. Deeper cavities must be filled beforehand.
4. Once the first layer of filler has dried, apply a second layer with a float.

DRYING TIME

- The drying time depends upon the layer thickness, temperature and atmospheric humidity.
- Average drying time: 8 to 10 hours.

For more information visit: www.keim.com/en-gb/literature