



APPLICATION INSTRUCTIONS - KEIM ECOTEC

KEIM Ecotec is a solvent free, silicone micro-emulsion based hydrocarbon concentrate for use as an environmentally friendly water repellent and dust suppressant.

BEFORE PROCEEDING

- Allow a minimum of 15 days for new renders/repairs to dry.
- Lime renders/repairs must be allowed a minimum of 28 days to dry and must have carbonated to a minimum depth of 2.5mm.
- Ensure air and surface temperatures are between 5-30°C.
- Ensure surface moisture content to a depth of 5mm is below 18%.
- Do not apply when there is a likelihood of rainfall within 12 hours.

SURFACE PREPARATION

- Wash all surfaces with clean cold water to remove dust and dirt.

MATERIAL APPLICATION

- Mix Keim Ecotec to a ratio of 1:9 with clean cold water (1-part Keim Ecotec + 9 parts water).
- This mixture is to be used within 24 hours of mixing.
- Apply Keim Ecotec either with low pressure spray in a flood coat manner or saturate with a brush from top to bottom.

For more information visit: www.keim.com/en-gb/literature