



APPLICATION INSTRUCTIONS - KEIM ECOSIL GRUND (GRUNDIERWEISS)

KEIM Ecosil Grund is a silicate-based primer coat for interior use.

BEFORE PROCEEDING

- Allow a minimum of 15 days for new plaster/repairs to dry.
- Lime plaster/repairs must be allowed a minimum of 28 days to dry and must have carbonated to a minimum depth of 2.5mm.
- Ensure air and surface temperatures are between 5-30°C.
- Ensure surface moisture content to a depth of 5mm is below 18%.

SURFACE PREPARATION

- Remove unstable material back to a sound edge with a stiff brush or scraper. All remaining material must be sound and adhering well.
- Sand gloss or shiny surfaces to create a key.
- Fill cracks or equalise the surface using KEIM Dolomitspachtel where required.
- Wash all surfaces with clean cold water to remove dust and dirt.

MATERIAL APPLICATION

1. Apply KEIM Ecosil Grund undiluted by brush or roller.
2. **Allow a minimum of 5 hours before proceeding with decoration.**

SUBSEQUENT COATS

- KEIM Ecosil Grund must be over coated with one coat of KEIM Ecosil.

For more information visit: www.keim.com/en-gb/literature