



## APPLICATION INSTRUCTIONS - KEIM INNOSTAR

KEIM Innostar is an interior one-coat white paint system.

### BEFORE PROCEEDING

- Allow a minimum of 15 days for new plaster/repairs to dry.
- Lime plaster/repairs must be allowed a minimum of 28 days to dry and must have carbonated to a minimum depth of 2.5mm.
- Ensure air and surface temperatures are between 5-30°C.
- Ensure surface moisture content to a depth of 5mm is below 18%.

### SURFACE PREPARATION

- Remove unstable material back to a sound edge with a stiff brush or scraper. All remaining material must be sound and adhering well.
- Sand gloss or shiny surfaces to create a key.
- Fill cracks or equalise the surface using KEIM Dolomitspachtel where required.
- Wash all surfaces with clean cold water to remove dust and dirt.

### MATERIAL APPLICATION

#### BARE LIME PLASTER, ABSORBENT OR POROUS SURFACES

- Apply undiluted KEIM Granital Dilution by brush, work well into the surface and allow a minimum of 12 hours before proceeding.

#### LIMEWASHED OR DUSTING SURFACES

- Apply KEIM Fixativ diluted 50:50 with clean cold water by brush, work well into the surface and allow a minimum of 12 hours before proceeding.

---

#### UNPAINTED & PREVIOUSLY PAINTED SURFACES

- Apply a single, undiluted coat of KEIM Innostar by brush, roller or airless spray, working the material well into the surface, maintaining a wet edge and working to a natural breakline.

For more information visit: [www.keim.com/en-gb/literature](http://www.keim.com/en-gb/literature)