



## APPLICATION INSTRUCTIONS - KEIM SOLDALIT GROB

KEIM Soldalit Grob is a primary coat and filler for the KEIM Soldalit system. Can be used to bridge hairline cracks and equalise the surface.

### BEFORE PROCEEDING

- Allow a minimum of 15 days for new renders/repairs to dry.
- Lime renders/repairs must be allowed a minimum of 28 days to dry and must have carbonated to a minimum depth of 2.5mm.
- Ensure air and surface temperatures are between 5-30°C.
- Ensure surface moisture content to a depth of 5mm is below 18%.
- Do not apply when there is a likelihood of rainfall within 12 hours.

### SURFACE PREPARATION

- Remove unstable material back to a sound edge with a stiff brush or scraper. All remaining material must be sound and adhering well.
- Sand gloss or shiny surfaces to create a key.
- Remove organic growth using a stiff brush. Apply KEIM Algicide where required.
- Fill cracks or equalise the surface using KEIM Spachtel where required.
- Wash all surfaces with clean cold water to remove dust and dirt.

### MATERIAL APPLICATION

1. Apply KEIM Soldalit Grob undiluted by brush, roller or airless spray.
2. **Allow a minimum of 12 hours before proceeding with decoration.**

### SUBSEQUENT COATS

- KEIM Soldalit Grob must be over coated with one or two coats of KEIM Soldalit.
- Allow at least 12 hours drying time between individual coats.

For more information visit: [www.keim.com/en-gb/literature](http://www.keim.com/en-gb/literature)