

SkyVac Internal Model Assembly/User Guide

skyVac™ SkyVac 30 Internal 8 Pole Package



SkyVac Assembly



Always use the Filter to protect the Motor

The drum cartridge must be kept in place at all times. Dust & debris will collect inside the bin
Alternatively fit filter bag with drum filter to collect debris inside the bag this will also give ultra fine filtration **KEEP FILTER CLEAN**

Push the flexi hose vac cuff into vac port





Connect poles together to the desired height. Select you tool holder and fit into suction pole then select your brush attachment and fit onto tool holder.

Push end cuff over your base pole



Select end tool to suit application

GOOD PRACTISE

Don't

Force the suction pole joints together.
Ensure the joints are free from dust and grit before putting together. Wipe the joints with a damp cloth. Grit can lock the joints up!

Do's

Occasionally spray the carbon fibre joints with Silicone Spray
Keep filters clean in your vacuum to keep retain suction power
When connecting poles together ensure they are free from grit and debris to prevent premature wear.