

TOUGH-COTE HIGH BUILD EM18

IMPORTANT APPLICATION METHODS

ROLLER

- **HEAVILY LOAD** a foam 'cigarette burn' roller for High Build finish, or a standard foam roller for a lower texture.
- With **VERY SLOW** even strokes, lay onto wall in heavy patches. Do not worry about the texture at this point in time.
- When the initial quantity of product is on the wall, slowly and evenly spread out to cover a larger area.
- The texture can now be achieved by further rolling and jointing of areas using a diagonal action. The texture is achieved by laying off.
- Always finish on the up stroke, in order to push the marble aggregate into vertical position. This will ensure that the texture will have a 'peaked' effect when dry.
- Window reveals etc, can be rolled as close as possible and then finished with a brush in order to give a professional flat border finish.

USING THE ABOVE METHODS LARGE AREAS CAN BE COVERED QUICKLY WITH AN EVEN PROFESSIONAL FINISH.