

## Hardtop CA

---

### Product description

This is a two component acrylic coating. The product does not contain isocyanates, neither does it generate di-isocyanates during hotwork / welding or fire. It has a glossy finish with good colour and gloss retention. It is a high solids product. The product has good application properties with low dry spray. To be used as topcoat in atmospheric environments.

### Scope

The Application Guide offers product details and recommended practices for the use of the product.

The data and information provided are not definite requirements. They are guidelines to assist with efficient and safe use, and optimum service of the product. Adherence to the guidelines does not relieve the applicator of responsibility for ensuring that the work meets specification requirements. Jotuns liability is in accordance with general product liability rules.

The Application Guide (AG) must be read in conjunction with the relevant specification, Technical Data Sheet (TDS) and Safety Data Sheet (SDS) for all the products used as part of the coating system.

### Referred standards

Reference is generally made to ISO Standards. When using standards from other regions it is recommended to reference only one corresponding standard for the substrate being treated.

---

### Surface preparation

The required quality of surface preparation can vary depending on the area of use, expected durability and if applicable, project specification.

When preparing new surfaces, maintaining already coated surfaces or aged coatings it is necessary to remove all contamination that can interfere with coating adhesion, and prepare a sound substrate for the subsequent product.

Inspect the surface for hydrocarbon and other contamination and if present, remove with an alkaline detergent. Agitate the surface to activate the cleaner and before it dries, wash the treated area using fresh water. Paint solvents (thinners) shall not be used for general degreasing or preparation of the surface for painting due to the risk of spreading dissolved hydrocarbon contamination. Paint thinners can be used to treat small localized areas of contamination such as marks from marker pens. Use clean, white cotton cloths that are turned and replaced often. Do not bundle used solvent saturated cloths. Place used cloths into water.

#### Process sequence

Surface preparation and coating should normally be commenced only after all welding, degreasing, removal of sharp edges, weld spatter and treatment of welds is complete. It is important that all hot work is completed before coating commences.

### Coated surfaces

#### Organic primers/intermediates

The surface of previous coats shall be free from contamination by water, hydrocarbon based products, wax, mud, mortar droppings and loose, chalked and flaking coating.

Inspect the surface for hydrocarbon and other contamination and if present, remove with an alkaline emulsifying detergent. Agitate the surface to activate the cleaner and before it dries, wash the treated area by low-pressure water cleaning (ISO 8501-4) using fresh water. Surfaces not contaminated with hydrocarbon deposits shall be washed according to ISO 12944-4, section 6.2.1 Water cleaning using fresh water to reduce surface chlorides. When applied on coatings past maximum over coating interval light abrading may be required to achieve proper intercoat adhesion.

### Inorganic zinc silicates

This product can be applied on top of an inorganic zinc ethyl silicate, provided the primer is cured and the product is applied using a mist-coat technique.

## Application

### Acceptable environmental conditions - before and during application

Before application, test the atmospheric conditions in the vicinity of the substrate for the dew formation according to ISO 8502-4.

|                        |         |    |
|------------------------|---------|----|
| Air temperature        | 5 - 50  | °C |
| Substrate temperature  | 5 - 60  | °C |
| Relative Humidity (RH) | 10 - 85 | %  |

The following restrictions must be observed:

- Only apply the coating when the substrate temperature is at least 3 °C (5 °F) above the dew point
- Do not apply the coating if the substrate is wet or likely to become wet
- Do not apply the coating if the weather is clearly deteriorating or unfavourable for application or curing
- Do not apply the coating in high wind conditions

## Product mixing

### Product mixing ratio (by volume)

|                   |           |
|-------------------|-----------|
| Hardtop CA Comp A | 9 part(s) |
| Hardtop CA Comp B | 1 part(s) |

### Induction time and Pot life

|                          |              |
|--------------------------|--------------|
| <b>Paint temperature</b> | <b>23 °C</b> |
| Pot life                 | 4 h          |

The temperature of base and curing agent is recommended to be 18 °C or higher when the product is mixed.

### Thinner/Cleaning solvent

Thinner: Jotun Thinner No. 7 / Jotun Thinner No. 17

### Application data

#### Spray application

##### Airless Spray Equipment

|                                 |                  |
|---------------------------------|------------------|
| Pump ratio (minimum) :          | 42:1             |
| Pressure at nozzle (minimum) :  | 150 bar/2100 psi |
| Nozzle tip (inch/1000) :        | 15-21            |
| Nozzle output (litres/minute) : | 1.3-1.9          |
| Filters (mesh) :                | 70               |

Several factors influence, and need to be observed to maintain the recommended pressure at the nozzle. Among factors causing pressure drop are:

- extended hoses or hose bundles
- extended hose whip-end line
- small internal diameter hoses
- high paint viscosity
- large spray nozzle size
- inadequate air capacity from compressor
- incorrect or clogged filters

##### Air Spray Equipment

|                                |                                                      |
|--------------------------------|------------------------------------------------------|
| Pressure at nozzle (minimum) : | HVLP: 2.4 bar/ 34 psi / Pressure pot: 2.4 bar/34 psi |
| Nozzle tip:                    | HVLP: 13-21 (inch/1000) / Pressure pot: 1.3-2.1 (mm) |

## Film thickness per coat

#### Typical recommended specification range

|                            |                            |
|----------------------------|----------------------------|
| Dry film thickness         | 60 - 125 µm                |
| Wet film thickness         | 100 - 210 µm               |
| Theoretical spreading rate | 10 - 4.8 m <sup>2</sup> /l |

Bright colours may need film thickness in the high end of the recommended specification range to achieve opacity.

Can be applied up to 25 % higher than maximum specified film thickness without loss of technical properties.

## Film thickness measurement

#### Wet film thickness (WFT) measurement and calculation

To ensure correct film thickness, it is recommended to measure the wet film thickness continuously during application using a painter's wet film comb (ISO 2808 Method 1A). The measurements should be done as soon as possible after application.

Fast drying paints may give incorrect (too low) readings resulting in excessive dry film thickness. For multi layer physically drying (resoluble) coating systems the wet film thickness comb may give too high readings resulting in too low dry film thickness of the intermediate and top coats.

Use a wet-to-dry film calculation table (available on the Jotun Web site) to calculate the required wet film thickness per coat.

#### Dry film thickness (DFT) measurement

When the coating has cured to hard dry state the dry film thickness can be checked to SSPC PA 2 or equivalent standard using statistical sampling to verify the actual dry film thickness. Measurement and control of the WFT and DFT on welds is done by measuring adjacent to and no further than 15 mm from the weld.

### Ventilation

Sufficient ventilation is very important to ensure proper drying/curing of the film.

### Coating loss

The consumption of paint should be controlled carefully, with thorough planning and a practical approach to reducing loss. Application of liquid coatings will result in some material loss. Understanding the ways that coating can be lost during the application process, and making appropriate changes, can help reducing material loss.

Some of the factors that can influence the loss of coating material are:

- type of spray gun/unit used
- air pressure used for airless pump or for atomization
- orifice size of the spray tip or nozzle
- fan width of the spray tip or nozzle
- the amount of thinner added
- the distance between spray gun and substrate
- the profile or surface roughness of the substrate. Higher profiles will lead to a higher "dead volume"
- the shape of the substrate target
- environmental conditions such as wind and air temperature

## Drying and Curing time

| Substrate temperature     | 5 °C | 10 °C | 23 °C | 40 °C |
|---------------------------|------|-------|-------|-------|
| Surface (touch) dry       | 6 h  | 4 h   | 2.5 h | 2 h   |
| Walk-on-dry               | 72 h | 36 h  | 5 h   | 5 h   |
| Dry to over coat, minimum | 72 h | 36 h  | 5 h   | 5 h   |
| Dried/cured for service   | 28 d | 14 d  | 12 d  | 3 d   |

Drying and curing times are determined under controlled temperatures and relative humidity below 85 %, and at average of the DFT range for the product.

Surface (touch) dry: The state of drying when slight pressure with a finger does not leave an imprint or reveal tackiness.

Walk-on-dry: Minimum time before the coating can tolerate normal foot traffic without permanent marks, imprints or other physical damage.

Dry to over coat, minimum: The recommended shortest time before the next coat can be applied.

Dried/cured for service: Minimum time before the coating can be permanently exposed to the intended environment/medium.

## Maximum over coating intervals

Maximum time before thorough surface preparation is required. The surface must be clean and dry and suitable for over coating. Inspect the surface for chalking and other contamination and if present, remove with an alkaline detergent. Agitate the surface to activate the cleaner and before it dries, wash the treated area by low-pressure water cleaning using fresh water.

If maximum over coating interval is exceeded the surface should in addition be carefully roughened to ensure good inter coat adhesion.

### Areas for atmospheric exposure

Average temperature during drying/curing

5 °C    10 °C    23 °C    40 °C

Itself

extended extended extended extended

## Quality assurance

The following information is the minimum required. The specification may have additional requirements.

- Confirm that all welding and other metal work has been completed before commencing pre-treatment and surface preparation
- Confirm that installed ventilation is balanced and has the capacity to deliver and maintain the RAQ
- Confirm that the required surface preparation standard has been achieved and is held prior to coating application
- Confirm that the climatic conditions are within recommendations in the AG, and are held during the application
- Confirm that the required number of stripe coats have been applied
- Confirm that each coat meets the DFT requirements in the specification
- Confirm that the coating has not been adversely affected by rain or other factors during curing
- Observe that adequate coverage has been achieved on corners, crevices, edges and surfaces where the spray gun cannot be positioned so that its spray impinges on the surface at 90° angle
- Observe that the coating is free from defects, discontinuities, insects, abrasive media and other contamination
- Observe that the coating is free from misses, sags, runs, wrinkles, fat edges, mud cracking, blistering, obvious pinholes, excessive dry spray, heavy brush marks and excessive film build
- Observe that the uniformity and colour are satisfactory

All noted defects shall be fully repaired to conform to the coating specification.

### Caution

This product is for professional use only. The applicators and operators shall be trained, experienced and have the capability and equipment to mix/stir and apply the coatings correctly and according to Jotun's technical documentation. Applicators and operators shall use appropriate personal protection equipment when using this product. This guideline is given based on the current knowledge of the product. Any suggested deviation to suit the site conditions shall be forwarded to the responsible Jotun representative for approval before commencing the work.

For further advice please contact your local Jotun office.

### Health and safety

Please observe the precautionary notices displayed on the container. Use under well ventilated conditions. Do not inhale spray mist. Avoid skin contact. Spillage on the skin should immediately be removed with suitable cleanser, soap and water. Eyes should be well flushed with water and medical attention sought immediately.

### Accuracy of information

Always refer to and use the current (last issued) version of the TDS, SDS and if available, the AG for this product. Always refer to and use the current (last issued) version of all International and Local Authority Standards referred to in the TDS, AG & SDS for this product.

### Colour variation

Some coatings used as the final coat may fade and chalk in time when exposed to sunlight and weathering effects. Coatings designed for high temperature service can undergo colour changes without affecting performance. Some slight colour variation can occur from batch to batch. When long term colour and gloss retention is required, please seek advice from your local Jotun office for assistance in selection of the most suitable top coat for the exposure conditions and durability requirements.

### Reference to related documents

The Application Guide (AG) must be read in conjunction with the relevant specification, Technical Data Sheet (TDS) and Safety Data Sheet (SDS) for all the products used as part of the coating system.

When applicable, refer to the separate application procedure for Jotun products that are approved to classification societies such as PSPC, IMO etc.

## Symbols and abbreviations

|                                                  |                                                     |
|--------------------------------------------------|-----------------------------------------------------|
| min = minutes                                    | TDS = Technical Data Sheet                          |
| h = hours                                        | AG = Application Guide                              |
| d = days                                         | SDS = Safety Data Sheet                             |
| °C = degree Celsius                              | VOC = Volatile Organic Compound                     |
| ° = unit of angle                                | MCI = Jotun Multi Colour Industry (tinted colour)   |
| µm = microns = micrometres                       | RAQ = Required air quantity                         |
| g/l = grams per litre                            | PPE = Personal Protective Equipment                 |
| g/kg = grams per kilogram                        | EU = European Union                                 |
| m <sup>2</sup> /l = square metres per litre      | UK = United Kingdom                                 |
| mg/m <sup>2</sup> = milligrams per square metre  | EPA = Environmental Protection Agency               |
| psi = unit of pressure, pounds/inch <sup>2</sup> | ISO = International Standards Organisation          |
| Bar = unit of pressure                           | ASTM = American Society of Testing and Materials    |
| RH = Relative humidity (% RH)                    | AS/NZS = Australian/New Zealand Standards           |
| UV = Ultraviolet                                 | NACE = National Association of Corrosion Engineers  |
| DFT = dry film thickness                         | SSPC = The Society for Protective Coatings          |
| WFT = wet film thickness                         | PSPC = Performance Standard for Protective Coatings |
|                                                  | IMO = International Maritime Organization           |
|                                                  | ASFP = Association for Specialist Fire Protection   |

## Disclaimer

The information in this document is given to the best of Jotun's knowledge, based on laboratory testing and practical experience. Jotun's products are considered as semi-finished goods and as such, products are often used under conditions beyond Jotun's control. Jotun cannot guarantee anything but the quality of the product itself. Minor product variations may be implemented in order to comply with local requirements. Jotun reserves the right to change the given data without further notice.

Users should always consult Jotun for specific guidance on the general suitability of this product for their needs and specific application practices.

If there is any inconsistency between different language issues of this document, the English (United Kingdom) version will prevail.